MIX BACK HEADPHONE OUT TO WEDGE
MONITOR SELECTOR

STANDARD GUITAR
A/B FOOT SWITCH

INSERT CABLE

OUT A
MB HP OUT L

TO AMP INPUT

INPUT

OUT B
MB HP OUT R

NOTE, INSURE SWITCH IS
BREAK-BEFORE MAKE SWITCH